

# CH Products FLIGHT SIM Yoke

## Sample button assignments

### SAMPLE PROGRAMMABLE \* A SSIGNMENTS

Button	Name	Function
1	Trigger	Look Center
3	Rocker Switch 1	Map Screen
4	Rocker Switch 1	Instrument Screen
5	Left Toggle(up)	Flaps Up
6	Left Toggle(down)	Flaps Down
7	Right Toggle(up)	Gear Up
8	Right Toggle(down)	Gear Down
9	Push Button 1	Look Up
10	Push Button 2	Look Down
11	Rocker Switch 2	Trim Down
12	Rocker Switch 2	Trim Up
↑	8-way Hat Switch	View Front
←	8-way Hat Switch	View Left
→	8-way Hat Switch	View Right

**USB PORT**  
connection

