

200-568 Combatstick Button Assignments



X Axis = Joystick Handle Turning Left and Right. In FS2020, assign "Ailerons Axis" to "Joystick L-Axis X"

Y Axis = Joystick Handle Pushing Back and Forth. In FS2020, assign "Elevator Axis" to "Joystick L-Axis Y"

Z Axis = Left Black Wheel. In FS2020, assign "Throttle Axis" to "Joystick L-Axis Z"

Button 1 = Index Trigger

Button 2 = Left Position Red Button

Button 3 = Front Gray Button

Button 4 = Pinky Red Button

Button 5 = Back Side Red Button

Button 6 = Top Red Button

Buttons 7 through 10 = Four Way Hatswitch

POV Hatswitch = 8 Directions